


Required tools




PK.1005 / 01

800.566.1986 | BALDWINHARDWARE.COM


1 Install exterior trim and cylinder

Installation des garnitures extérieures et des cylindres
Instalar la moldura exterior y el cilindro




3 Extend latch bolt with supplied keys

Sortir le pêne demi-tour à l'aide des clés fournies
Extienda el pestillo con las llaves suministradas




2 Install interior adapter

Installer l'adaptateur intérieur
Instalar adaptador interior



4 Install interior turnpiece

Installer le tourniquet intérieur
Instalar la pieza giratoria interior



TEMPLATE

Plantilla
Gabarit

